



## Self-priming multi-stage centrifugal pump

Type: **TVS**  
**KS**




### 1 CHECKING


- 1-1. Has the model as ordered been delivered?  
Check the model, bore, capacity, total head, shaft power etc., on the name plate.
- 1.2. Are there any damage or any loosen bolt, nuts or screw, etc., on transit?
- 1.3. Are all accessories supplied?  
Standard accessories
  - 1 pc. Strainer
  - 1 set Foundation bolts with nuts.
  - 1 pc. Operation manual

### 2 INSTALLATION AND PIPING


- 2-1. Installation site  
Select the site as close to the water resource as possible, and do not expose the unit to rain.
- 2-2. Piping  
Observe the following instructions.



## 2-3. Installation of Pump proper



## 3 TRIAL OPERATION



\* It is desirable that the gland packings tightened to such a condition that a small quantity of water leaks. (1-2 drops per second)

## 4

## MAINTENANCE

Daily Maintenance	<ul style="list-style-type: none"> <li>* The cocks of the pressure gauge and vacuum gauge are supposed to be closed when the gauges are not being read. Open their cocks only when their data are read.</li> <li>* Do not operate the pump for a long period time at the pressure or capacity out of standard as the life time of pump becomes shorter.</li> <li>* Do not operate the pump in idle or closing the sluice valve for a long period of time. If this is done, the inside of the pump will get burnt.</li> </ul>
Under Operation	<ul style="list-style-type: none"> <li>* Stop the operation after closing the sluice valve on the discharge line.</li> <li>* When power suspends while the pump is under operation, cut off the switch immediately and close the sluice valve on the discharge line.</li> </ul>
Periodical Inspection	<ul style="list-style-type: none"> <li>* Check the following points at least once a week.               <ol style="list-style-type: none"> <li>1) Pressure gauge &amp; Vacuum gauge Does the pointer of the gauge register the rated value? Does the pointer of the gauge move violently?</li> <li>2) Does water leak from the pump or piping?</li> <li>3) Is there any abnormality about the vibration, noise or heat at the bearing portion?</li> </ol> </li> </ul>
Long Suspension of Operation	<ul style="list-style-type: none"> <li>* Drain the water inside the pump from drain nipple.</li> </ul>
Protection Against Cold	<ul style="list-style-type: none"> <li>* Pump . . . . . Cover the pump with a wooden box, and place protection materials inside the box.</li> <li>* Pipe . . . . . Provide with protection materials or bury the pipe under the ground. (In Tokyo or Osaka, about 30cm in depth)</li> <li>* Drain the water inside the pump via the drain nipple.</li> </ul>
Gland Packing	<ul style="list-style-type: none"> <li>* Always store spare gland packing. (Gland packing is consumable parts, so, replace it once a year in ordinary cases, or twice a year, if necessary.)</li> <li>* Do not fix the gland packing too tight or uneven, because the sealing portion generates heat and makes the life time of gland packing shorter.</li> </ul>

## 5

## DISASSEMBLING AND REASSEMBLING

## 5-1. Order of disassembling


(46) Sealing pipe → (38) Stage bolt → (51) Bearing cover → (33) Suction casing →  
 (56) Impeller nut → (59) Impeller → (31) Stage casing → (61) Sleeve → (63) Impeller key →  
 (35) Bracket → (65) Bearing cover → (62) Shaft

\* Order of reassembling is reverse of disassembling.

## 5-3. Caution

- a) Be careful not to give damage to the parts when disassembling and reassembling.
- b) Be careful with the tightness of gland packings.
- c) Do not forget to reassemble even small parts.
- d) Be sure that the pump rotates smoothly rotating the shaft coupling by hand after completion of reassembling.


**PARTS LIST: KS**



**KS**

No.	Name of Parts	No.	Name of Parts	No.	Name of Parts
1	Suction flange bolt	29	O-ring for discharge casing	65	Bearing cover (inboard-2)
2	Suction flange	30	3/8" plug	66	Ball bearing (outboard-2)
3	Suction check valve	31	Stage casing	67	Bearing washer
5	3/8" plug	33	Suction casing	68	Bearing cover (outboard-2)
7	Priming cap	34	O-ring for suction casing	69	Bearing cover bolt-2
8	Priming cap packing	35	Bracket	70	Deflector-2
9	Washer	36	Bracket bolt	71	Ball bearing (inboard)
10	Bolt	38	Stage bolt	77	Gland-2
11	Priming body	39	Nut for stage bolt	78	Gland bolt-2
12	Exhaust elbow	40	Suction panel	79	Gland packing-2
13	Priming elbow	41	Suction panel bolt	80	Gland nut-2
19	Drain cap	44	Guide vane	84	Base
20	Drain cap packing	45	O-ring for guide vane	85	Pump bolt
21	Drain nipple	56	Impeller nut	88	Shaft coupling
22	Drain elbow	58	Impeller washer	90	Motor shim
23	Discharge flange	59	Impeller	91	Coupling guard
24	Discharge flange bolt	61	Sleeve	92	Coupling guard bolt
25	Nut for discharge flange bolt	62	Shaft	93	Corrugated washer
26	Discharge flange packing	63	Impeller key	94	Plain washer
28	Discharge casing	64	Coupling key		

**PARTS LIST: TVS**



**TVS**

No.	Name of Parts	No.	Name of Parts	No.	Name of Parts
1	Suction flange bolt	35	Bracket	65	Bearing cover (inboard-2)
2	Suction flange	36	Bracket bolt	66	Ball bearing (outboard-2)
3	Suction check valve	37	O-ring for bracket	67	Bearing washer
5	3/8" plug	38	Stage bolt	68	Bearing cover (outboard-2)
7	Priming cap	39	Nut for stage bolt	69	Bearing cover bolt-2
8	Priming cap packing	42	Stage panel	70	Deflector-2
9	Washer	43	Stage panel bolt	73	Gland-1
10	Bolt	46	Sealing pipe	74	Gland bolt-1
11	Priming body	48	Seal bush	75	Gland packing-1
12	Exhaust elbow	49	Grease thrower	76	Gland nut-1
19	Drain cap	50	Bearing cover bolt-1	77	Gland-2
20	Drain cap packing	51	Bearing cover (outboard-1)	78	Gland bolt-2
21	Drain nipple	52	Ball bearing (outboard-1)	79	Gland packing-2
23	Discharge flange	53	Collar	80	Gland nut-2
24	Discharge flange bolt	54	Bearing cover (inboard-1)	84	Base
26	Discharge flange packing	55	Deflector-1	85	Pump bolt
28	Discharge casing	56	Impeller nut	88	Shaft coupling
29	O-ring for discharge casing	59	Impeller	91	Coupling guard
30	3/8" plug	61	Sleeve	92	Coupling guard bolt
31	Stage casing	62	Shaft	93	Corrugated washer
33	Suction casing	63	Impeller key	94	Plain washer
34	O-ring for suction casing	64	Coupling key		

TROUBLE	CAUSE	REMEDIES	TROUBLE	CAUSE	REMEDIES
Motor does not start	<ul style="list-style-type: none"> <li>Defective motor</li> <li>Pump is seized with impurities or rust.</li> </ul>	<ul style="list-style-type: none"> <li>Check power source.</li> <li>When the pump cannot be turned by hand, disassemble and clean.</li> </ul>		<ul style="list-style-type: none"> <li>Air leaks</li> <li>Seized impeller or suction piping</li> <li>Insufficient rotation speed.</li> <li>Opposite rotation direction</li> <li>Too high suction head</li> <li>Too high discharge head</li> <li>Worn parts.</li> </ul>	<ul style="list-style-type: none"> <li>Refasten the parts and inspect sealing portion.</li> <li>Clean the impeller or suction piping.</li> <li>Inspect the power source or motor.</li> <li>Correct the rotation direction by changing any two of three wirings.</li> <li>Check the water level.</li> <li>Check the actual discharge head.</li> <li>Replace parts.</li> </ul>
No water lifts after starting	<ul style="list-style-type: none"> <li>Improper pump level</li> <li>Insufficient priming water</li> <li>Air accumulation is found inside the pipeline.</li> <li>Opposite rotation direction.</li> <li>Plugged passage.</li> <li>Insufficient rotation speed.</li> <li>Closed valve.</li> <li>Foot valve or the end of suction pipe does not reach water.</li> </ul>	<ul style="list-style-type: none"> <li>Too high suction head or too long suction pipe.</li> <li>Adjust the site or piping.</li> <li>Prime water again.</li> <li>Inspect the piping conditions.</li> <li>Correct the rotation direction by changing any two of three wirings.</li> <li>Remove impurities from the impeller, suction piping, valves, strainer, etc.</li> <li>Inspect the power source or motor.</li> <li>Inspect the valves.</li> <li>Extend the length of suction pipe.</li> </ul>	No. specified specifications is obtained.	<ul style="list-style-type: none"> <li>Operation out of standard specification</li> <li>Too high suction head.</li> <li>Impurities stuck on the impeller or suction and discharge piping</li> </ul>	<ul style="list-style-type: none"> <li>Correct operation as specified.</li> <li>Inspect the level of water.</li> <li>Inspect the impeller, suction piping, or discharge piping</li> </ul>
			Abnormal sound is audible		

**KAWAMOTO PUMP FMG, Co., LTD.**

No. 11-39, 4-Chome, Ohsu  
Naka-ku, Nagoya, Japan